



<b>średnica węża</b>	<b>oznaczenie końcówki</b>	<b>rozmiar gwintu średnica kołnierza</b>	<b>s.o.</b>
8	RNMA DN08 - D16	M16 x 1,5	1
8	RNMA DN08 - D18	M18 x 1,5	2
10	RNMA DN10 - D18	M18 x 1,5	1
12	RNMA DN12 - D18	M18 x 1,5	1
16	RNMA DN16 - D22	M22 x 1,5	1